


Reflection Control Panel

CATS-REF-CP

Install Instructions



Complete Acoustic Treatment System



Required materials – not included

1. 3.5 x 25mm bugle head black drywall screw (4 per panel)
2. Optional – Builders Adhesive eg Evo-Stik Grip Fill



STEP 1 - PREPARATION

Surfaces where panels will be installed must be clean with no dust or debris which may interfere with the installation. We recommend using a damp cloth or decorators wipe to ensure that the area is free of surface dust.



STEP 2 - LAYOUT

Mark out where the panels will be installed. Pay attention for obstructions that may interfere with your planned layout.


C-ATS is designed to be a flexible and forgiving solution. Panels can be moved as much as 300mm (12") without major impact on the performance. It is easier and better to move a panel than to cut the panel wherever possible.



STEP 3 – OPTIONAL – APPLY ADHESIVE

This step is optional but does result in slightly improved performance at the expense of firmly sticking the panels to the wall behind.

Apply a thin bead of adhesive to the flat sections on the back of the panel. In particular the inner square is the best place to apply the adhesive.



STEP 4 – FIX WITH SCREWS

The panel should be fixed in place with 4x 25mm black drywall screws. These should be fixed through the countersunk holes moulded into the panel face.

In most cases there is no requirement to pre-drill or use wall fixing plugs, however it is the responsibility of the installer to ensure that the panel is fixed safely and securely.



COMPLETE ACOUSTIC TREATMENT SYSTEM
272 Bath Street, Glasgow, UK

www.c-ats.co.uk
info@c-ats.co.uk